





Scan the QR code or link to the address below to find a list of datasheets to all products and other support information.

https://www.tm-readers.com/downloads.htm

## Overview

The RX4 SPACER is an optional extra, providing a low profile mounting base to the RX4 advanced access control readers.





 ${\it Please call}~ + 44~ (0)~ 1495~ 751~ 992~ to~ discuss~ your~ custom~ configuration~ or~ LEGIC @~ reader~ requirements.$ 



Dimensions Housing

Mounting Fixing

96 x 52 x 13 mm (3.8 x 2.1 x 0.5 inches)

ABS

Suitable plain surface 4mm., max' diameter



(spacer with RX4 fitted)


## **MODEL**


**RX4 SPACER** 

The unit replaces the standard backplate to the reader, offering an alternative method of mounting the module, especially when fitting security projects to existing architecture and using 13mm square conduit cable trunking. The spacer also allows a convenient method of fixing the reader to a desktop, or most other plan surface finishes, giving a greater stand-off to the reader module.

The SPACER provides several screw hole fixing points with a defined cable access to the reader, and easier positioning of wiring to the reader's connection  $% \left( 1\right) =\left( 1\right) \left( 1\right)$ 

Made of tough ABS the spacer affords a firm and solid backing to the reader, and gives a professional look to the finished installation.





## Key features

- UK design and manufacture
- Black matt finish
- Tough ABS
- Slim profile

All copyrights © and trademarks ® / ™ are acknowledged and remain the property of their respective owners



'MIFARE', 'MIFARE Classic' and 'MIFARE DESFire' are trademarks of NXP B.V.