





Scan the QR code or link to the address below to find a list of datasheets to all products and other support information.

https://www.tm-readers.com/downloads.htm



Overview

The RXswitch is not an RFID reader, but an electronic unit designed to work seamlessly with the RXseries® of advanced access control readers. The switch unit will separate multiple card technologies into individual data feeds for independent access control systems within a multi-tenanted environment.




• Please be aware, the tenant is responsible for managing who may enter the building on their behalf.

Reader Models are sold as customer-specific configurations.

Please call +44 (0) 1495 751 992 to discuss your custom configuration or LEGIC® reader requirements.

MODEL	Current mA	Voltage Vdc	Wiegand
RXswitch	25 (typical)	5 - 16	•





Dimensions 105 x87 x 16 mm (4.1 x 3.4 x 0.6 inches) Housing Moulded polycarbonate / stainless steel Mounting Suitable plain surface

Fixing 4mm., max' diameter

Operating temp' -35°C to +66°C

Humidity 85±5% at 30±2°C (86±3°F)

Ingress IP67

Voltage see table below Current see table below

Rest >4Vdc / Active <1Vdc Data Voltage

Data output see table below

Indication NONE (reader / control panel)

Sounder NONE

Termination Pluggable screw terminal blocks (supplied)

Key features

- UK design and manufacture
- Black gloss finish
- Slim profile
- Fully encapsulated electronics
- Range of input/output formats
- 5 year limited warranty
- Pluggable terminal block connections



	HE	1	-	OV	Supply voltage to ground
~	HE	2	-	+Vdc	Supply voltage (+5Vdc to +16Vdc)
	HEX	3	-	DATA0 IN	Wiegand input
ADE	HEK	4	-	DATA1 IN	Wiegand input
READER INPUT	HE	5	-	GREEN OUT	Green LED control output
# =	HEX	6	-	TXD	RS232 transmit line
		7	-	RXD	RS232 receive line
	FEK	8	-	+5Vdc OUT	100mA max
	HE	1	-	OV	Supply voltage to ground
Λ	HE	2	-	DATA0 OUT	Wiegand output
Δ	HE	3	-	DATA1 OUT	Wiegand output
		4	-	GREEN IN	Green LED control input
	HE	1	-	OV	Supply voltage to ground
B	HEX	2	-	DATA0 OUT	Wiegand output
		3	-	DATA1 OUT	Wiegand output
	HEL	4	-	GREEN IN	Green LED control input
	HE	1	-	OV	Supply voltage to ground
	<u> </u>	2	-	DATA0 OUT	Wiegand output
		3	-	DATA1 OUT	Wiegand output
	HE	4	-	GREEN IN	Green LED control input
		_			
	HE	1	-	0V	Supply voltage to ground
	HE	2	-	DATA0 OUT	Wiegand output
	H	3	-	DATA1 OUT	Wiegand output
	FE	4	-	GREEN IN	Green LED control input









All copyrights © and trademarks ® / ™ are acknowledged and remain the property of their respective owners.



'MIFARE', 'MIFARE Classic' and 'MIFARE DESFire' are trademarks of NXP B.V.






Stacking

The RXswitch may be 'stacked' to offer up to 4 multiples of 4 tenants (or zones) within a building.

The diagram below shows a typical wiring setup and arrangement to accommodate up to 16 tenants (or zones) within a multi-storey or departmental complex

Please be aware the tenant is responsible for managing who may enter the building on their behalf.













All copyrights © and trademarks ® / ™ are acknowledged and remain the property of their respective owners.



100-03062-RXswitch-F

SERIES © Third Millennium Systems Ltd registered in England & Wales No. 3199053

Third Millennium Systems Ltd.

18 / 19 Torfaen Business Centre
Panteg Way New Inn PONTYPOOL NP40LS United Kingdom

'MIFARE', 'MIFARE Classic' and 'MIFARE DESFire' are trademarks of NXP B.V.